Cranium Camera Crane Rentals

cranium.tv



Operations Manual



BEFORE YOU START, READ THESE WARNINGS

- 1) NEVER PLUG POWER DEVICES OTHER THAN THOSE SUPPLIED BY PACIFIC MOTION INTO THE SYSTEM. ONLY USE PACIFIC MOTION POWER SOURCES AND CABLES. USING DIFFERENT POWER COMPONENTS CAN LEAD TO SEVERE DAMAGE TO THE HEAD AND EVEN THE CAMERA. THIS TYPE OF DAMAGE IS NOT COVERED UNDER WARRANTY.
- 2) DO NOT MODIFY THE SUPPLIED CABLES OR ATTEMPT TO DISASSEMBLE THE HEAD.
- 3) LENS CONTROL CABLES MUST ONLY BE PLUGGED INTO THE SPECIFIED INPUT JACK ON THE LENS ITSELF - <u>NEVER PLUG A</u> <u>12-PIN CONNECTOR ON A PACIFIC MOTION LENS CONTROL CABLE</u> <u>INTO THE 12PIN JACK ON THE CAMERA BODY</u>. WHEN IN DOUBT, CONSULT PACIFIC MOTION OR YOUR LENS MANUAL.
- 4) THE ADVANCED CONTROLLER DOES NOT REQUIRE SEPARATE POWER, IT RECEIVES POWER THROUGH THE GREEN-CODED CONTROL CABLE THAT CONNECTS TO THE HEAD. THE "AUX" POWER JACK ON THE ADVANCED CONTROLLER IS ONLY UTILIZED IN WIRELESS CONFIGURATIONS AND SHOULD ONLYBE CONNECTED TO A PACIFIC MOTION POWER SUPPLY.
- 5) DO NOT OPERATE THE HEAD WITH AN UNBALANCED LOAD (i.e., with the camera's weight extremely off-center either horizontally or vertically).
- 6) DO NOT GET THE SYSTEM WET IT IS NOT WATERPROOF.
- 7) MAKE SURE YOUR LENS CLEARS THE BASE OF THE HEAD WHEN TILTING. IF THE LENS DOES NOT CLEAR THE BASE, SET SOFT LIMITS (SECTION 7) TO PREVENT THE LENS FROM STRIKING THE BASE OF THE HEAD WHEN TILTING.

General Description

The Talon is a mid-size, two axis repeatable remote head. It has a wide variety of operating modes: manual operation from joystick, optional hand wheels or pan bars control, motion control style record and playback, "go to mark" preset framing, intervalometer operation and can operate as a slave to Kuper Node motion control. It also is capable of providing motion data for virtual set operation.

The Talon Advanced Controller gives the user all input and programming capabilities and has a joystick for pan & tilt control. The Advanced Controller also works in concert with two optional control input devices: Pan Bars for broadcast-style operation or Hand Wheels for cinemastyle operation.

The Jibstick remote is a simpler, less expensive controller designed for one-man jib operation. The jibstick only offers joystick pan & tilt with smoothing and speed control.

The Talon's lens interface controls zoom, focus and iris. It provides four varieties of control signals: RS-232 for Fujinon digital lenses or Pacific Motion (TOC) motor drives, RS-422 for Canon digital lenses or Preston motor drives, position or speed based analog, pulse width type RC servos, and LANC.

The following is an in-depth description of Talon operation and a complete description of each of its features.

Talon Advanced Controller

Front Panel buttons: – The top row of buttons default to act like a normal record - playback system; record, rewind, stop and play. The top left button, 'Q', is used as a 'Shift' key. The bottom row includes:

The "Menu" button = '*' The "Accept" button = '<-' The "Cancel" button = 'x'



The main page may always be enabled by pressing the "Cancel" button one to three times, depending on which sub-menu you start out from.



The upper right portion of the LCD screen shows motor status and current positions for pan, tilt, zoom and focus. A check in the box to the left of the axis name indicates that that motor is enabled to run. If soft limits are enabled for the axis, the box is filled and appears white with a blue check mark. The numbers to the right of the axis names are the motor positions; pan and tilt are shown in degrees, and zoom and focus are shown as an unscaled number from 0 to 1000.

1. Navigating the menu screens

Use the knob above the joystick to navigate through the menu screen. This knob (called the setup knob) will also be used to change the value of selected parameters.

Use the "enter" button to select an item. The "menu" button is used to enter setup menu.



When pressed while already in the setup menu, the "menu" button will enter a second setup menu.



The "cancel" button is used to cancel the last item changed, or to back out of a sub menu. Pressing "cancel" twice will always return to the main screen.

The "Q" button is basically a shift key, and is used to change the function of other buttons.

The "Record" "rev" "stop" and "play" are used for the motion control features. This will be addressed later on.

The main menu screen will show pan, tilt, zoom, and focus positions. It will also display which take is enabled, which go to mark is enabled, as well as a few basic functionality adjustments.

When changing the value of a parameter, the setup knob will increase or decrease the value in increments of 1. Hold the "Q" button while moving the setup knob, and the values will move in increments of 10. Hold the "menu" button while moving the setup knob, and values will move in increments of 100. Hold both the "Q" and "menu" buttons while moving the setup knob, and the values will change in increments of 1,000.

Display Contrast can be adjusted from the second setup menu. While in the main screen, press the "menu" button twice. Select the "contrast" option. Contrast can be adjusted from 0-100

2. Basic Setup

Secure Talon head to crane, tripod, or solid mounting beam Plug the FACTORY POWER SUPPLY into AC mains Connect XLR cable between the Talon head and FACTORY POWER SUPPLY Connect in Green LEMO connector between the Talon head and the plug marked "CTRL" on the controller

Connect camera control (if applicable) between the camera and the 12-pin LEMO connector on the back of the tilt arm on Talon head .

Connect camera power (if applicable) between the 2-pin LEMO connector also located on the back of the tilt arm Connect the bloop/sync (if applicable) between the camera and the 6-pin Fischer connector also located on the back of the tilt arm

If using the TOC system

Connect the TOC 3A (3 axis lens drive box) between the orange 16-PIN lens control connector located on the front of the tilt arm of the Talon head, and the grey "control" port located on the TOC 3A

Connect the Lens drive motors to the appropriate connection according to their function (zoom, focus, iris)

If using a Preston MDR2*

Connect the MDR2 box between the 16-pin LEMO connector located on the front of the tilt arm of the Talon head, and the appropriate command connected on the MDR2 box (refer to the manufacturer's instruction manual for proper connections) Connect the Preston lens motors according to their manufacturer's instruction manual

* make sure that the MDR2 is not connected to any power source (including batteries) prior to connecting to the head. This can result in damages to the control console. The MDR2 will get all necessary power directly from the head.

Balance the Camera – Although the head will hold position very well, it operates best when the camera is balanced on the mounting platform. With heavier cameras, it is essential, as an out-of-balance load will cause the servos to constantly fight to hold position. Make sure that the motor power is turned off before balancing. This will allow you to move the tilt axis by hand. To balance the camera horizontally, you need to place the camera's front-to-back center of mass at the center of the mounting platform slot. You can do this by trial and error, sliding the camera front-to-back on the mounting platform until it stays level.

The simplest accurate way to find the camera's center of mass is to lay a pencil/pen on a table and try to balance the camera on it front-toback. The spot on the camera where it comes closest to balancing on the pencil is the center of mass. Place the camera's center of mass at the center of the mounting slot and secure the camera with mounting screws (2 if possible). When horizontally balanced, the platform should stay level.



With smaller cameras (under 10lbs), you may not need to adjust the vertical balance. For larger cameras, you may want to adjust it for optimal performance and to minimize the effort the servos have to make to hold position. To get the vertical balance right, raise or lower the platform to get the camera's vertical center of mass located on the center of tilt rotation. To adjust, you will have to loosen the lockdown screws (2) on each of the camera platform tubes. Once they are loose, turn the fluted knob on the underside of the platform (between the tubes) to precisely raise or lower it. Rotate the platform to various angles and adjust until it holds position at any angle. If it falls down, you need to adjust the platform upward. If it drifts upward, you need to lower the platform. Note that if you can't get the vertical balance just right, the head will compensate when the servos are powered up. When balance is achieved, tighten the lockdown screws on the platform tubes.

After all connections have been made and the camera is balanced, the head will be ready for initial calibration.

Switch on power located on the power brick.

Switch on the Talon head power located on the controller (the power switch on the left)

After sync is established (a spinning diamond will appear in the lower left corner of the remote. After the diamond stops spinning, sync is established between the Talon head and the controller), switch on motor power (the power switch on the right)

Calibrate "Home sense". This will calibrate the sensors so that the position markers will be accurate. This needs to be done any time one of the axes is moved while power is off, or if the Talon head has been operated in oneway communication mode.

Select "GoTo" from the main menu screen. Then select "Home" from the sub menu. The screen will then read "ready to calibrate?". Press "enter" again, and the head will then calibrate home sense.

Set inputs- You will now need to set the Talon head to respond to the correct controller inputs.

Press the "menu" button to bring up the setup menu.

Select the "inputs" option. This will bring up a controller inputs grid.



Here is where you can assign how Pan, Tilt, Zoom, and Focus will be controlled. Move the cursor box to where you'd like to control each axis. **Note:** Make sure you have the correct controller selected. I.E. if you are using wheels, make sure "wheels" is selected rather than "panbar". This will greatly effect the performance of the Head.

Overslung/Underslung- Make sure this selected for the proper configuration. If this needs to be changed, simply move the cursor box over the selection, and press "enter". This will change the Pan response.

Lens- This only needs to be changed if you are using camera lens controls other than the TOC system. In other words, if you're connecting directly to a Canon or Fujinon lens servo, or even a Preston system, you'll need to go into this menu to set things up properly.

Press the "menu" button to enter the main setup menu. Select the "Lens" option.

Current Lens: Default			Current Lens: Preston				
Zoom:	2.50	5.00	7.50	Zoom:	2.50	xxx	7.50
Focus:	2.50	xxx	7.50	Focus:	2.50	xxx	7.50

When the "Current Lens" box is selected, pressing "enter" will change the selection.

Preston

If you are using a Preston MDR2, press the "enter" button until the box reads "Preston."

Canon or Fujinon Analog Servos

If you are using a Canon or Fujinon lens with an <u>analog</u> zoom servo, press the "enter" button until "default" appears.

Connect the Lens Control Cable

To set up the lens control, you need to first connect the lens cable to the servo jack(s) on the lens itself (NEVER connect to the jack on the camera body where the lens plugs in, or damage may occur). You will plug into the same jack(s) where you would plug in any external lens control, so consult your owner's manual if necessary.

Adjust the Voltages

You must then adjust the voltages in the lens menu so the lens servo responds properly – you may notice the lens zooming on its own when you first connect the cable, but this is normal. Start by adjusting the middle number until the lens servo stops zooming. If the lens is all the way at one end of the range, you may need to manually zoom the lens in or out to reset the position in order to see if the servo is still moving. (Some people also flip the lens servo switch to manual and just listen to hear the servomotor stop running)

Once you've set the middle number to the proper rest voltage, you need to make sure the voltages on the left and right are equally far from the middle "rest" voltage. In other words, if your rest voltage is 4.00, the left voltage could be 1.50 and the right 6.50.

If the difference is unequal, you'll notice the lens zooms faster in one direction than the other. The greater the difference, the faster the lens will zoom in that direction. The left number should always be lower than the middle number and the right number should always be higher than the middle number.

Canon or Fujinon Digital Servos

If you are using a Canon or Fujinon lens with **digital** servos, press "enter" until the lens manufacturer's name appears. Digital servos should automatically work with no setup.

Head Setup- Press the "menu" button twice to enter the secondary setup menu.

Select the "head setup" option.

If you are using the Head wired, change the "communication" box to read "two-way", and change the "head type" to read "wired"

If you are using the Head wireless, change the "communication" box to read "one-way", and change the "head type" to read "wireless"

Warning: In the "Head setup" menu, there is also a set of head speed options: "S-Standard," "HS - High Speed" and "HSX – Ultra Speed" – DO NOT CHANGE THIS SETTING FROM "S – Standard" – THE CP SHOULD ALWAYS BE SET TO "S – Standard", unless you special ordered a high-speed custom head, in which case the factory would have already preset the correct selection in this menu.

3. Basic operation and adjustments

WARNING: If your lens has an optical image stabilizer (OIS), we recommend that you disable the OIS. The motion of the head may cause the OIS to exhibit some strange behavior. In some cases, the OIS may create the illusion that the head is drifting at 90 degrees to the axis of motion (e.g., at the end of a pan move, the image may "tilt" slightly up or down). Turn off the OIS to prevent optical problems.

The Head can control Pan, Tilt, Zoom, Focus, and record start/stop (when available from the camera) from the advanced controller, and has programmable parameters for each axis. Iris can also be controlled from an optional FIZ controller.

Pan, tilt, and zoom can be controlled with the joystick by moving the joystick forward, backward, left, right, or twist for zoom.

Pan and Tilt can also be controlled by using the optional encoded handwheels or with the optional panbar controller pan and tilt to be controlled as if using a fluid head. This can also be fitted with optional Pro style zoom and focus controls.

Focus is controlled with the knob to the left.

Record start/stop is done by holding the "Q" button and pressing the "enter:" button. A "C" (for camera) will appear next to the "Go To" option when camera record has started.

Speed adjustment

Basic speed adjustment for pan and tilt can be made in the main menu screen. Move the cursor box to "spd" using the setup knob, and press "enter". The setup knob will then change the speed for both pan and tilt (the number shown in the box is a percentage of the advanced speed setting). Pressing the "enter" button again will allow you to change the advanced speed setting. In this menu the setup knob will adjust tilt speed, and the focus knob will adjust pan speed. The number shown in the box is a percentage of full speed capability. Press enter again to keep your selection, and return to the main screen.

4. Motion response

From the main screen press the "menu" button, Select the "response" menu.



Here you can adjust parameters for Pan, Tilt, zoom, and focus. Select the axis that you'd like to adjust.

Smoothing will adjust how "quick" the axis will respond. Smoothing can be adjusted from 1-100. 1 being instant response, and 100 being the maximum delay in response. Smoothing will also affect the how quick the axis will slow down while making the move.

Speed will adjust the advanced speed setting. The numbers in the box are the same numbers that appear in the advanced speed setting accessible from the main screen. **Deadband** only affects the joystick. It will adjust the amount the joystick must be moved before the axis responds. Deadband can be adjusted from 1-100. 1 being minimum amount of movement before response, and 100 being maximum amount of movement before response.

Direction- In will change the direction in which the signal is sent to the head. It is what you will need to change to reverse axis responds. I.E. if tilt is set + turning the encoded

wheel clockwise will tilt the camera up, and pressing the joystick forward will tilt the camera down. If it is changed to – turning the encoded wheel clockwise will tilt the camera down, and pressing the joystick forward will tilt the camera up.

Direction- Out will change the direction in which the head sends the signal back to the controller. This will change the axis positions on the main screen display as they relate to zero. I.E. a pan maneuver from left to right will have decrease the angle if the output direction is marked as+. Switching the output direction to – will result in the angle number increasing when a pan maneuver is made from left to right.

5. Motor Enable/Disable

To enable or disable control of pan, tilt, zoom, or focus, or to place pan or tilt in neutral, while in the main screen select the "ENL" option.



The cursor box then appears in the top right corner, and lets you select one of the four axes. Move the cursor over which axis you wish to control.

Pressing "enter" will disable, or enable that axis from the controller. When disabled, power will remain to this axis, so it will hold its position. It will just be disabled from control.

While holding "Menu", press the "enter" button. This will place the selected axis (this only works for pan or tilt) in neutral. That axis not only will be disabled from the controller, and will no longer be powered allowing you to move the axis by hand. From this menu, you can also set each axis for live playback, or manual control (this only applies when playing back a move which will be addressed in a later chapter)

Note: A check mark next to the axis indicated that the axis is enabled.

An "x" next to the axis indicates the axis is disabled.

An "o" next to the axis indicates an axis that is in neutral.

A blue check mark with a white background indicates an axis with a soft limit set If the name of the axis appears blue with a white background, this indicates an axis that is set for live control during playback of a move (this will be addressed in a later chapter)

6. Setting Zero

You can custom set the axis position indicator to read zero wherever is necessary. Move each axis to your desired zero point**.

From the main screen select the "set" option. Then a sup menu will appear to the right. Select the "zero" option.

All axes will then reference their current position as zero.

**If using the TOC system, Preston MDR2, or any Canon of Fujinon lens with digital servo control. Setting zero will only affect pan and tilt. Zoom, and focus will be referenced to the actual motor position.

You can always return all axes to zero at any time. From the main screen, select "Go To" From the sub menu, select "Zero" All axis will then return to the zero position

7. Soft Limits

Soft limits will allow you to limit the range of the pan, tilt, zoom, or focus axes. This is very useful if you have any hard wired cables that will restrict pan or tilt movement, or any lenses that limit clearance. You can set two limits per axis.

From the main screen select the "set" option. A sub menu then will appear to the right. Select the "soft limits" option.



Select the axis that you'd like to set soft limits.

When setting a limit, leave the soft limit as "disabled" Move the selected axis to the desired limit. Then select "set limit" Now move the axis in the other direction to where you need the other limit set. Select "set limit" Now move the cursor box to "Disabled", and press "enter" The box now shows "enabled", and your soft limits are set that that particular axis. **Note:** If the system is setup to be in "one-way" mode, you can quickly enable or disable pan and tilt soft limits from the main screen.

While in the main screen Hold "Q" and press "record". This will enable or disable pan and tilt soft limits.

Reset Zero will set the current position of the selected axis to read as zero.

Set Default will automatically set the selected axis to +900 and -900 from its current position. This is just for a quick limit set that doesn't require the operator to have the head in any direction.

Reference is the point from where the soft limits are set. You can change this to "sensor" or "zero". If reference is set to "zero" then the limits will be set based on how far the axis is from the zero position. In this case, the soft limits will change position if zero is reset. If "sensor" is selected, the limits will be set regardless of where their zero position is. In this case, if you reset zero the soft limits will not change their position. **Note:** If any axis is moved by hand while the Head is not powered, the sensor position will have changed once it is powered up again. You must then re-calibrate "home sense" (as addressed in the previous chapter) in order to restore the soft limits to their correct positions.

8. Mark points

The controller can store 2,000 preset positions for any axis.

Setting Marks

To set a mark point, select "Mark" on the main screen.

Take 1 Mark 1	✓ pan ✓ tilt ✓ zoom	-1.4 2.1 265.7
Go to	< focusi	289.7
Set Enl Sed: 100	Mark P: num <u>I</u> :	-1.4
Sync: • •	1 部	289.7

The number in the box will indicate where your mark will be stored. As you scroll through the numbers, the lower right will display the current positions recorded for each mark.

Once you choose where you want to store the mark, press "enter"

Move the axes to the position that you wish them to set for this mark position. Select the "set" option.

From the sub menu select "Mark"

This will then record all current axes positions to the mark displayed in the upper left.

Recalling Marks

To recall a mark position, select the "Mark" number you wish to recall from the main screen. (The axis positions will be displayed in the lower right)

Select the "Go To" option



From the sub menu, select "Mark"

All axes will go to the position that is recorded for this mark.

Note: A quick way to scroll through marks. While holding the "Q" key, press "Play" and the mark numbers will increase. Press "Stop" and the mark numbers will decrease. This is much faster than scrolling with the setup knob.

Jog Time is the speed and time that the Head will take to move to and from a mark, or to and from zero. This can be adjusted for linear ramping, and will be addressed in more detail in a later chapter.

9. Recording moves

The Talon can record up 4,650 seconds of moves, and store them as up to 2,000 different takes. They will be played back in real time, or over an intervalometer (The intervalometer will be addressed in a later chapter)

Recording a move- Select the take where you want to store the move. From the main screen, move the cursor box to the number next to the "take" option..



From here, you can select the take where you want to store your move.

The bottom left will display how long the existing take is (if it is empty it will display "0"), and how many seconds are available for recording in the system's memory.

Press the "record" button. If a move is already stored it will read "overwrite take?" Press enter to overwrite. It will then read "hit record to start"

Once you hit record, it will instantly begin recording the moves for all applicable axes (pan, tilt, zoom, focus, and iris)

When you are done, press the "stop" button

Note: You can record a "go to mark" maneuver.

Before you begin recording, make sure that the desired mark is already displayed in the upper left.

Begin recording.

Any time during the recording hold the "Q" button and press "play". The Head will then automatically move from the current position to the mark point displayed in the upper left. This can be done as many times as necessary during the recording.

Playing back a move- Select the take that you wish to play back

Press the "play" button. All recorded axes will then move to the starting point of the selected take.

After the all axes have returned to the start point, press "play" again, and the Head will play back the recorded move.

Note: During playback of a move, the joystick, panbars, or handwheels, will be disabled until the axes are done playing back the move.

Manual control on axes during playback- It is possible to isolate a specific axis or axes to be disabled from playing back while the other axes play back the move. From the main screen select the "enl" option. Then select which axis you'd like to disable from playback On the lower left, next to "playback" it will display either "active" or "live" When "active" is displayed, the axis will be played back during a move. When "Live" is selected, the axis will be disabled from playback, but you will be able to control that axis with the controller while the other axes playback the move.

Note: When selecting a take for playback, or recording, hold the "stop" button while turning the setup knob. This will skip to the next take that has a move recorded. I.E. if you have a move recorded on take 2, and a move recorded on take 12, and moves 3-11 are blank, this will scroll the numbers directly from take 2 to take 12.

Delete a take- Select the take that you want to erase.

While holding "stop" press "record" This will then erase the move that is stored on the selected take.

10. The Intervalometer

The intervalometer allows recorded moves to be played back over a specified time and, when camera sync is enables, will control the number of frames that will be taken during that time. To activate the intervalometer, select the "record/play" option from the setup screen.

Select "playback time".



The intervalometer has three modes. "Playback Time Mode", "Playback Ratio Mode", and "Stop Motion Mode".

-Playback Time Mode

This mode allows you to select a specific time that the head will take to play out a recorded move.

Adjust the time you wish for the move to be played back. (the playback time selected must be **greater** than the move time)

Move the cursor box over "disabled", and select it. It will then change to "enabled", and all moves will be played back according to these settings.

If you have "camera sync" enabled, you can select the number of frames that will be taken during the selected time. The "Start Frame" setting will allow you to start in the middle of a take, if you ever need to replay a move, but don't need to replay if from the beginning. Setting the "Start Frame" to anything other than one will start the move from the position that corresponds to the selected frame.

Note: all of these settings will be applied to all recorded moves. If a move has a greater recorded time than what the intervalometer is set to, the move will not play until the intervalometer is either disabled, changed to a different mode, or the playback time is adjusted to be greater than that of the selected take.

-PB Ratio Mode

This mode allows you to change the playback of a move according to the frame rate. The "Rec FPS" will adjust the invervalometer to record the move at this specified frame rate. The "Play FPS" will adjust how the move is played back. For example; if a move is recorded at 30Fps, and the Playback is set to 15Fps, the move will play back at half speed.

This mode will also allow you to play a move faster than it was recorded. If the Play Fps is set higher than the Rec Fps, the move will be faster than is was recorded.

-Stop Motion Mode

This mode allows you to play back a move by triggering it frame by frame. This works much like a "frame mode" on a camera. When this mode is selected, the move will be scaled down according to the "playback frames". After you set the number of playback frames, return to the main menu, and select your desired move, and press the "play" button. The head will then move to the start position. From now on, each time you press the "play" button, the head will move to the position that corresponds to the next frame until the total number of frames is reached.

If "camera sync" is enabled, the head will trigger the shutter each time the "play" button is pressed.

***You can also adjust the delay between when the shutter is triggered and when the head moves to the next frame. If you change the intervalometer back to "Playback Time"

Mode", the time specified here will be the shutter delay time when operated in "Stop Motion Mode". After you select the desired shutter delay time, change the intervalometer back to "Stop Motion Mode". The shutter delay will now be set. (set it to "0" if no shutter delay is desired)

11. Bloop Delay/Camera Sync

Bloop delay will allow you to choose the number of seconds before it will take for the head to begin playing back a move after the "play" button is pressed. This can be used in conjunction with a bloop light or trigger.

Sync is where you can synchronize move playback with your camera's shutter pulse. When both "Sync" and the intervalometer are enabled, the Cinemapro will trigger the camera shutter according to the number of playback frames during playback.

"sync" will also allow you to feed the Cinemapro a frame pulse from film cameras. When "sync" is turned on, the head will synchronize the move according to the frame pulse. If there is any lag in this, you can use the "cam phase" to adjust the difference. **Virtual sync** is used to generate a virtual "frame pulse" when using a digital format camera or any camera that doesn't give a frame pulse. This will sync the move to whatever FPS you specify in this menu.

12. Jog Time

Jog time is the time the Head will take to or from a mark or zero. Select "Jog Time" from the setup menu

Jos time: 📃	4.0 seconds
Jos motion:	S - curve
Linear ramp:	5 percent

Under the "jog time" option, you can set the number of seconds the Head will take to go from mark to mark, from zero to mark, or from mark to zero.

Under "jog motion" you can choose either "s-curve" or "linear". This is how the speed will vary throughout the motion.

"s-curve" will start slow, speed up, then slow down before all axes reach their destination.

"Linear" will start slow, and then increase speed. Maximum speed will be reached at no more than 50% of the move.

"linear ramp" will adjust the percentage of the move the Head will take to reach full speed in while "linear" is selected.

13. PT-Z

PT-Z is the menu where you can change the Pan/Tilt sensitivity according to the position of the zoom axis.



PT-Z can be adjusted between 0-100. The greater the number the slower the pan and tilt axes will respond according to the position of the zoom axis. When 0 is selected, zoom will not affect the pan and tilt axes.

Note: This is only accurate when using the Pacific Motion TOC system, Preston MDR2, Canon lens with digital servos, or Fujinon lens with digital servos. If you are using a Canon or Fujinon lens with Analog Servos, the zoom positions will not be accurate, and with feature will not function properly.

14. Servo Tuning

Servo tuning is changed from the "tuning" option in the second setup menu.



These settings are factory preset, and should never be changed. If they have been changed, they must be changed back to the following, or the Pan and Tilt motors can be damaged.

KP: 80	KI:15
KD:250	IL: 25

After the setting is made, move the cursor box to the "ok" option, and press "enter". The settings will not be saved until this is done. Settings should be the same for both pan and tilt axes.

15. System resets

The "reset all" option is found in the second setup menu screen. When selected this will reset all parameters only. All stored marks, and takes will not be effected.

To reset all motor parameters only, turn the console power off

Hold the "cancel" and "stop" button simultaneously. While holding both buttons turn console power on.

The screen will then read "Accept = reset all motors"

Press the "enter" button, and all motor parameters will be reset.

To erase all takes turn console power off.

Hold the "cancel" and "record" buttons simultaneously. While holding both buttons turn console power on.

The screen will then read "Accept = erase all takes" Press the "enter" button, and all takes will be erased.

To erase all marks turn console power off.

Hold the "cancel" and "play" buttons simultaneously. While holding both buttons turn console power on.

The screen will then read "Accept = erase all marks"

Press the "enter" button, and all marks will be erased

Note: resetting all motor parameters is recommended after updating system software. It is also recommended if the systems memory ends up corrupted.

16. Troubleshooting

No Response from head

1) Check the "inputs" settings to make sure that the controller (joystick, handwheels, or panbars) you're using is selected.

2) Make sure that the motor power switch is turned on, and the light above it is green.

3) If using a wireless module, check the "head setup" menu to make sure that "wireless" and "one way" are selected.

4) If using handwheels, or Panbars, first make sure that they're selected in the "inputs menu", then make sure that they are plugged into the "PB-W" connector on the back of the console.

5) Make sure all motors are enabled. Go to the main screen, and make sure that there is a white checkmark next to Pan, Tilt, Zoom, and Focus.

6) Check to make sure that there aren't any soft limits set too close together. Disable all soft limits, and then try again.

7) Power down the system, unplug the XLR connector, wait for a few seconds, re-plug everything back in, power it back up, then try again.

8) Perform all of the system resets.

Head is "jerky" or too responsive

1) If using handwheels or panbars, check the "inputs" menu, and make sure that the proper controller is selected

2) If using a wireless module, make sure that the head is set for "wireless" and in "one-way". Also make sure that the two wireless transceivers are at least 15 feet away from each other.

3) In the "response" menu, increase the "smoothing" setting for each axis.

4) Turn down motor speed.

5) Check to make sure that the servo tuning in the "tuning" menu is set to the factory setting. Selecting "reset all" will return this to the factory preset .

6) Perform all system resets

Soft limits aren't accurate

1) Re-calibrate "home" sense. If the head has been moved while powered down, the home sense will be lost, and if the soft limits are set to "reference sensor", they will be lost as well.

2) If the soft limits are set to "reference zero", and your zero position has been changed, the soft limits will also chance with the new zero.

3) Perform all system resets, then re-set the soft limits in the "set limits" menu.

17. Options and Specs

Additional Software- The Talon head can operate as a slave to Kuper Node motion control software, and is also is capable of providing motion data for virtual set operation.

Data capture software is available, for data sharing. This will allow you to export the data from the Talon to a personal computer.

Additional Head options-

The Talon head can be fitted with either a 100mm half ball, or Mitchell mount. A Mitchell ring adapter is available for old style Mitchell mount. An adapter is also available to adapt Mitchell mount to Jimmy Jib style mount.

Wireless control is available, and can controlled from up to ¹/₄ mile. Up to 1 mile line of sight.

Additional controller cables are available in 50' or 100' increments. A male to female LEMO coupler is available to join the cables.

Talon XLR power cables are available in 30' or 75' increments.

2" head extension blocks are available, and will increase the underslung clearance range from 16.5"-18.5" to 18.5"-20.5". A maximum of two can be installed. This will also increase clearance if using a larger lens.

 $\frac{1}{4}$ " or $\frac{1}{8}$ " nodal line offsets can be installed on the Talon's camera mounting plate to line of the center of the lens when necessary.

Dedicated video sliprings can be fitted on the Talon head to allow high quality SD video to pass through the head. There is a 2db signal loss through this dedicated slip ring, so HD SDI is not supported unless a line driver is introduced. This option will only support HD for monitoring purposes – the signal will not be of broadcast quality.

HD hardwiring is available for a broadcast-quality HD video signal. (This cable will bypass the slipring, and limit pan and tilt movements to 720°)

Specs-

Head construction: Primarily Aluminum, with carbon fiber platform rails and some stainless steel, steel, brass, bronze components

Height: 19.5"

Width: 12"

Depth: 6"

Weight: 21 lbs.

Maximum speed: 210 deg/sec (max up to 512 deg/sec with custom high speed motors)

Underslung Camera Clearance for Standard Head = 15.5" – 17.5" (camera platform adjusts 2" up/down)

Underslung Camera Clearance w/ Head Extensions: w/ 1 extension = 17.5" - 19.5"; w/ 2 Extensions = 19.5" - 21.5"

Mechanical travel: unlimited unless hardwired.

Camera Plate dimensions-

From Center mounting hole- tilt arm: 5" (with standard nodal line plate installed. This may be offset by $\frac{1}{4}$ " or $\frac{1}{8}$ " with offset nodal line plates installed)

Camera plate has 2" of vertical adjustment for camera balancing.

Connectors -

Talon Base connectors Head power- 4pin XLR Kuper Node- 6pin LEMO (red) Controller- 7pin LEMO (green) Video out- BNC



Tilt arm connector, front Lens control- 16pin LEMO (orange)





Tilt arm connectors, back Video in- BNC Bloop/sync (optional)- 6pin Fischer Camera control (optional)- 12pin LEMO (white) Camera Power- 2pin LEMO (red)

Advanced Controller connectors (not pictured)

CTRL - 7Pin LEMO – Head control cable (green) SERIAL - 8pin LEMO – TOC or Preston Lens Drive Hand Units (gray) ANALOG - 5pin LEMO – Pan Bars zoom & focus controls (white) WHEELS - 6pin LEMO – Handwheels or Pan Bars Control Input (blue) BLOOP - 6pin Fischer VIDEO SYNC – BNC connector

Appendix

Power Supply Connectors

1) Power Connector - XLR4F

Pin

Function

Wire Color

1	Camera Neg.	Black
2	Talon Neg	White
3	Talon Pos	Red
4	Camera Pos.	Green

2) Camera Power Connector

Pin	Function	Destination
1	Camera Neg.	Loop to Power Connector
2	N.C.	
3	N.C.	
4	Camera Pos.	Loop to Power Connector

*** WARNING: DO NOT POWER THE CINEMAPRO WITH ANYTHING OTHER THAN THE INCLUDED FACTORY POWER SUPPLY OR YOUR WARRANTY MAY BE VOIDED. THE UNIT MAY BE SEVERELY DAMAGED AND CAUSEDAMAGE TO YOUR CAMERA IF YOU USE A NON-APPROVED POWER SUPPLY.IF YOU MUST POWER IT USING A BATTERY SYSTEM, MAKE SURE THE SETUP IS APPROVED BY PACIFIC MOTION AND EXECUTED BY A QUALIFIED TECHNICIAN.

Talon Head - Base Connectors

1) Control Connector (green) - LEMO EGG1B307CLL

Pin	Function	Wire Color (Cal	ble)
1	Common	Brown	
2	RS-422 RXD	Red	
3	RS-422 RXD!	Orange	
4	RS-422 TXD	Yellow	
5	RS-422 TXD!	Green	
6	24 VDC +	Blue	Power to Remote or Jibstick
7	24 VDC -	Violet	Power to Remote or Jibstick

2) Kuper Node Connector (red) - LEMO EGG1B306CLL

Pin	Function	DB9
1	Common	1
2	N.C.	
3	RS-422 RXD (Kuper)	8
4	RS-422 RXD! (Kuper)	9
5	RS-422 TXD (Kuper)	5
6	RS-422 TXD! (Kuper)	6

3) * Optional - Camera Control Input Connector - EGG2B310CLL

Pin	Function
1	Common
2	12 VDC out
3	Run Switch
4	Remote Enl
5	Remote Clock
6	Remote Direction
7	Clock out
8	Sync out
9	N.C.
10	N.C.

4) * Optional - Peripheral Connector - EGG1B308CLL

Pin	Function
1	Common
2	#1 RS-232 RXD
3	#1 RS-232 TXD
4	+5 VDC
5	24 VDC -
6	#2 RS-232 RXD
7	#2 RS-232 TXD
8	24 VDC +

Talon Head - Tilt Arm Connectors

1)	Camera	Power	(red) -	LEMO	EGG2B302CLL
----	--------	-------	---------	------	-------------

Pin	Function
1	Camera Power +
2	Camera Power -

2) Sync & Bloop - Fischer D103A056-130

Pin	Function
1	Common - Iso
2	+5 VDC - Iso
3	Sync In
5	Bloop Out #1
6	Bloop Out #2

2) Camera Control (white) - LEMO EGG2B312CLL

Pin	Function
1	Common
2	Enable
3	Run - Pullup 12 volts
4	Run - O.C. to com
5	Run pulse - 5 VDC
6	Clock out - 5 VDC
7	Clock out - 12 VDC
8	Clock return
9	RS-232 TXD
10	RS-232 RXD

3) Lens Control (orange) - Tilt Board Version #2 LEMO EGG2B316CLL (Final Version)

Pin	Function	Lens Connection
1	RS-232 RXD	Fuji Digital
2	RS-232 TXD	Fuji Digital
3	+5 VDC - Iso	Fuji Digital
4	Common - Iso	Fuji Digital
5	RS-422 RXD	Canon Digital

itat
ital
ital

Lens Connection Table

Le	ns Control, 16 pin LEMO FG	G2B316CLAD				
		Fujinon Digital HR10A-10P-10P	Fujinon Analog HR10A-10P-12P	Fujinon Telecon HR10A-10J-12P	Canon Digital HR25-9P-20P	Canon Analog HR25-9P-20P
1	RS-232 RXD	3				
2	RS-232 TXD	2				
3	Iso Vcc	4				
4	IsoCom & IsoCom3	5			19 & 20 - Green	
5	RS-422 RXD				17 - Orange	
6	RS-422 RXD!				18 - Yellow	
7	RS-422 TXD				15 - Brown	
8	RS-422 TXD!				16 - Red	
9	Common		2	3		20
10	Vcc (5 volts)					
11	Analog #1 out		7 (If zoom)	9 (Zoom)		2
12	Analog #2 out		7 (If focus)	8 (focus)		3
13	RC Servo Out 1					
14	RC Servo Out 2					
15	Head power + out					
16	Head power - out					
				Tie pins 1 & 2 to 7		

for position control

Advanced Controller Connectors (console connectors)

1) Auxiliary power input

1	Center 18 to 36 volts input
2	Common

2) "CTRL" - Talon Control (green) - LEMO EGG1B307CLL

Function	Wire Color (Cab	le)
Common	Brown	
RS-422 RXD	Red	
RS-422 RXD!	Orange	
RS-422 TXD	Yellow	
RS-422 TXD!	Green	
24 VDC +	Blue	Power from Talon
24 VDC -	Violet	Power from Talon
	Function Common RS-422 RXD RS-422 RXD! RS-422 TXD RS-422 TXD! 24 VDC + 24 VDC -	FunctionWire Color (CabCommonBrownRS-422 RXDRedRS-422 RXD!OrangeRS-422 TXDYellowRS-422 TXD!Green24 VDC +Blue24 VDC -Violet

2) "SERIAL" - Peripheral Connector (gray) - EGG1B308CLL

Pin	Function
1	Common
2	#1 RS-232 RXD
3	#1 RS-232 TXD
4	+5 VDC
5	24 VDC -
6	#2 RS-232 RXD
7	#2 RS-232 TXD
8	24 VDC +

3) "ANALOG" - Panbars Option Zoom and Focus Control Input (white) - EGG1B305CLL

1	Common
2	Motor disable
3	Zoom analog signal
4	Focus analog signal
5	+5 VDC

4) "WHEELS" - Wheels and Panbars Option Control Input (blue) - EGG1B306CLL

1	Common
2	+5 VDC
3	Pan encoder signal "A"
4	Pan encoder signal "B"
5	Tilt encoder signal "A"
6	Tilt encoder signal "B"

5) "BLOOP" - Sync & Bloop - Fischer D103A056-130

1	Common - Isolated
2	+5 VDC - Isolated
3	Sync In
5	Bloop out #1
7	Bloop out #2

6) "VIDEO SYNC" - BNC

1	BNC signal
2	Isolated common

Jibstick Connectors

1) Talon Control (Green) - LEMO EGG1B307CLL

Pin	Function	Wire Color (Ca	able)
1	Common	Brown	
2	RS-422 RXD	Red	
3	RS-422 RXD!	Orange	
4	RS-422 TXD	Yellow	
5	RS-422 TXD!	Green	
6	24 VDC +	Blue	Power from Talon
7	24 VDC -	Violet	Power from Talon

2) Focus Input - Fischer D103A054-130

1	Common
2	+5 VDC
3	Focus analog signal
4	Zoom analog signal (unused)
5	Common

Pacific Motion

CONTROL

www.pacificmotion.net